



51 0768/00
D1
Gebrauchsanweisung
(D,GB,F,I,NL,DK,N)





TECHNISCHE DATEN / TECHNICAL DATA / DONNÉES TECHNIQUES

Verdichter/Compressor/Compresseur		Danfoss			
Typ/Type		TL 5 A			
Förderleistung/Delivery/Débit	l/h	V 920			
Anlaufstrom/Starting current/Cour. de démarrage	A	9,0			
Widerstand/Resistance/Résistance	Ha/main/prin.	Ω	15,7		
	Hi/aux	Ω	18,8		
Temp.-Regler/Thermostat		M + J			
Typ/Type		TF 57 SF			
Reglerstellung/Position		kalt	warm		
Schaltwerte/Switching values/	„ein“	- 28	- 19		
Valeurs de commutation	„aus“	- 34	- 26		
	(„abtauen“ od.)	„alarm“	- 20	- 15	
Füllmenge/Fill.quantity/Charge	R12	g	90		
Anschlußwert/Conn.load/Puiss. connectée		W	120		
Heizung/Heater/Chauffage					
Widerstand/Resistance/Résistance		Ω			
Leistung/Power/Puissance		W			
Ventilator/Blower/Ventilateur					
Widerstand/Resistance/Résistance		Ω			
Magnetventil/Magnetic valve/Electrovanne					
Widerstand/Resistance/Résistance		Ω			
Spannung/Voltage/Tension		V			

Pos.	D1			
	Danfoss			
1	14 0065/45			
2				
3	02 0108/27			
4				
5				
6	05 1413/05			
7				
8	11 0437/04			
9	05 0166/05			
10				
11				
12				
13				
14				