











07 4445




Gebrauchsanweisung
52 4355
(D,GB,F,I,NL,S,E,DK,N,,SF)

Montageanleitung
52 1893
(D,GB,F,I,NL,S,E,DK,N,,SF)

Befestigungssatz
26 7361




TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES

Verdichter/Compressor/Compresseur		Danfoss			
Typ/Type		NLY 13 K			
Förderleistung/Delivery/Débit	l/h	2637			
Anlaufstrom/Starting current/Cour. de démarrage	A	11,3			
Widerstand/Resistance/Résistance	Ha/main/prin. Ω	11,0			
	Hi/aux Ω	9,0			
Temp.-Regler/Thermostat		RCO K59			
Typ/Type		KER			
Reglerstellung/Position		kalt warm			
Schaltwerte/Switching values/	„ein“ $^{\circ}\text{C}$	+4,5 +4,5			
Valeurs de commutation	„aus“	-32,0 -21			
	(„abtauen“ od.) „alarm“				
Füllmenge/Fill.quantity/Charge	R600a g	*			
Anschlußwert/Conn.load/Puiss. connectée	W	150			
Heizung/Heater/Chauffage					
Widerstand/Resistance/Résistance	Ω				
Leistung/Power/Puissance	W				
Ventilator/Blower/Ventilateur					
Widerstand/Resistance/Résistance	Ω				
Magnetventil/Magnetic valve/Electrovanne					
Widerstand/Resistance/Résistance	Ω				
Spannung/Voltage/Tension	V				

* siehe Typenschild

Pos.	Danfoss		
	NLY 13K		
1	14 1747		
2			
3	15 1055		
4			
5	15 1053		
6	15 1072		
7			
8	28 1825		
9	05 0166		
10	05 9467		
11	26 6624		
12	05 6008		