











2) f. Flüssiggas

3) 08 2846/38 Thermostat) ab F-Nr.

4) 05 3393/13 Schalter) 5H - 20

u. 05 2859/04 Winkel)



1) A4

2) A5


3) B

5) 02 4572/02) ab F-Nr.

6) 02 4563/01)⁴F - 15

7) 02 4458/01)

8) 08 2846/38 Thermostat ab F-Nr. 5H - 20





Herde und Kücheneinrichtungen


Gasherd

2144/111 HECS

2194/111 HES

E-Nr. 11 2144 1101/1151/1191

E-Nr. 11 2194 1501/1551/1591



1) dazu: 02 3178/01/5 Scheibe


2) 12 5430/19) ab F-Nr. NF-46




NEFF Herde und Kücheneinrichtungen

Gasherd 2144/111 HEDS
2194/111 HES

E-Nr. 11 2144 1101/1151/1191
E-Nr. 11 2194 1501/1551/1591




**NEFF****Herde und Kücheneinrichtungen**Gasherd 2144/111 HECS
2194/111 HESE-Nr. 11 2144 1101/1151/1191
E-Nr. 11 2194 1501/1551/1591




NEFF Herde und Kücheneinrichtungen


Gasherd 2144/111 HEGS
2194/111 HES


E-Nr. 11 2144 1101/1151/1191
E-Nr. 11 2194 1501/1551/1591





1) f. Flüssiggas





1) A4

2) A5

3) B

4) 02 4572/02) ab F-Nr.