





Libro de instrucciones
50 0243
(es,pt)

1) Gas
15 1676
V01-V04
42 4646
V05,V06
Eléctrico
18 7606

2) Gas
18 7593
Eléctrico
18 7605



1) 18 4802
V01, V03, V05
18 7198
V02, V04
42 4754
V06

2) 18 9022

3) 18 4801
V01, V03, V05
18 7195
V02, V04
42 4758
V06

4) 18 4803
V01, V03, V05
18 7197
V02, V04
42 4756
V06

Cjtos. transformación:
Gas Butano
15 9769
Gas Natural
18 7193