






Libro de instrucciones  
51 7462  
(E, P, GB, F, NL, GR)

Libro instrucc. R600a  
51 9240  
(E, GB, F, P, D, I, NL, N, GR, DK, S, SF, TR)

Anexo ind. temp.  
52 0758  
(D, GB, F, I, NL, E, SF, S, N, GR, DK, P)

1) 06 7746  
2) 03 3055





| Pos. | ****               |                    |  |  |
|------|--------------------|--------------------|--|--|
|      | Aspera<br>BMP1084Y | Aspera<br>BMP1110Y |  |  |
| 1    | 14 1723            | 14 1605            |  |  |
| 2    | 15 4315            | 15 4315            |  |  |
| 3    | 16 7769            | 16 5230            |  |  |
| 4    |                    |                    |  |  |
| 5    |                    |                    |  |  |
| 6    | 26 4123            |                    |  |  |
| 7    | 05 0166            | 05 0166            |  |  |
| 8    | 28 0162            | 28 0162            |  |  |
| 9    |                    |                    |  |  |
| 10   |                    |                    |  |  |
| 11   |                    |                    |  |  |
| 12   |                    |                    |  |  |
| 13   |                    |                    |  |  |

| TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS       |                     |                    |    |  |
|-------------------------------------------------------------------------|---------------------|--------------------|----|--|
|                                                                         |                     | ****               |    |  |
| Verdichter/Compressor/Compresseur/Compresor                             | Aspera<br>BMP1084Y  | Aspera<br>BMP1110Y |    |  |
| Typ/Type/Tipo                                                           |                     |                    |    |  |
| Förderleistung/Delivery/Debit/Aspiración l/h                            |                     |                    |    |  |
| Anlaufstrom/Starting current/Cour.démarrage/Int.arranq. A               | 3,60                |                    |    |  |
| Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm                    | 29,60               | 24,70              |    |  |
| Hi/aux.                                                                 | 38,50               | 37,65              |    |  |
| Temp.Reyler/Thermostat/Termostato                                       | Danfoss<br>077B6161 | Ranco<br>K54-L1940 |    |  |
| Typ/Type/Tipo                                                           |                     |                    |    |  |
| Reglerstellung/Position/Conexión                                        | MIN. MAX.           | MIN. MAX.          |    |  |
| Schaltwerte/Switching values/                                           | ..ein/conex.°C      | +6° -14° -22°      |    |  |
| Valeurs de commutation/Desconex.                                        | ..aus"/descon.      | -11° -28°          |    |  |
| (..abtaven' od)                                                         | ..alarm'            | -10° -18°          |    |  |
| Füllmenge/Fill. quantily/Charge/Carga R600a                             | g                   | *                  | *  |  |
| Anschlusswert/Comm. load/Puiss. Connect./Potenc.                        | W                   | 71                 | 86 |  |
| Heizung/Heater/Chauflage/Resistenc.descong.                             |                     |                    |    |  |
| Widerstand/Resistance/Resistencia                                       | Ohm                 |                    |    |  |
| Leistung/Power/Puissance/Potencia                                       | W                   |                    |    |  |
| Ventilador/Blower/Ventilateur/Ventilador                                |                     |                    |    |  |
| Widerstand/Resistance/Resistencia                                       | Ohm                 |                    |    |  |
| Magnetventil/Magnetic valve/Electrovanne/Electrovalvula                 |                     |                    |    |  |
| Widerstand/Resistance/Resistencia                                       | Ohm                 |                    |    |  |
| Spannung/Voltage/Tension/Tensión                                        | V                   |                    |    |  |
| Temp.Reyler/Thermostat/Termostato ambiente para ventilador refrigerador |                     |                    |    |  |

\* Siehe Typenschild / See identification plate / Voir plaque de caractéristiques / Ver plaqueta de caracteristicas