




51 2521
 Gebrauchsanweisung
 51 2039
 Montageanleitung/Grill

Zubehör:

Back- und
 Bratrost normal
 Z1400X1

Back- und
 Bratrost eng
 Z1401X1

Grillpfanne
 Z1200X1

Email-Backblech
 Z1310X1


Alu-Backblech
 Z1300X1

Bratenblech
 Z1510X0

Drehspiess-Set
 Z1162X0

Brotbackstein
 Z1910X0

Grill 2,7kW
 Z1100X0



1) Düsensätze f.
 Stadtgas:
 02 1936
 Erdgas:
 02 1937
 Flüssiggas:
 05 2418

2) 02 6579

3) 05 2783

4) 05 4675

5) 05 4678

