





Gebrauchsanweisung
58 1076
(de,en,el)
Montageanleitung
51 7955
(de,en,fr,nl,it,es,el)
Kochbuch
52 1094
(de)


Zubehör:


Dampfgarer
N8640X0

Back,-u. Bratrost gekr.
Z1430X0
Back,-u. Bratrost engma.
Z1440X0
Bratenblech
Z1510X1
Brotbackstein
Z1910X0
Grillpfanne u. Bratrost
Z1230X0
Auflaufform
Z1270X0
Nachruestsatz Clou/Kat
Z1740X0
Nachruestsatz Clou4/Kat
Z1750X0



- 1) 18 3307
- 2) 18 3308
- 3) 18 3758





- 1) 48 3856
kompl.
- 2) 16 0916
- 3) 17 1146