




Gebrauchsanweisung


52 1502
(DE)
52 1503
(NL)
52 1504
(FR)
52 1505
(GB)
52 1506
(GR)

Montage- und
Aufstellanweisung
51 9653
(D,NL,F,E,GB,I,SF,F,S,
N,DK,P)

Programmtabelle

52 1509
(D)
52 1510
(NL)
52 1511
(F)
52 1512
(GB)
52 1513
(GR)

1) Blende kompl.
35 2036
Blendeneinlage 2)
mitbestellen



1) 29 7299
Set

Zubehör:

Höhenanpassung 91 cm:
WZ 10100

