





Gebrauchsanweisung
 58 4558
 (de,fr,nl,it)

Montageanleitung
 51 7991
 (de,en,fr,nl,it,es,pt,el)


Kochbuch
 58 4514

Zubehör:


Back-u. Bratrost-
 engmasching
 Z1440X0
 Back-u. Bratrost
 gekröpft
 Z1430X0
 Backblech Alu
 Z1330X0
 Backblech Email
 Z1340X2
 Universalpfanne u.
 Bratrost
 Z1230X2



- 1) 41 8601
- 2) 16 8588
- 3) 18 3036
- 4) 18 3035



- 1) 17 2765
- 2) 17 2646
- 3) 18 2627
- 4) 18 2428



- 1) 41 8562
- 2) 15 5033
- 3) 48 3856
- 4) 17 1146