





Gebrauchsanweisung
 52 3331
 de,fr,nl,it)
 Montageanleitung
 51 7991
 (de,en,fr,nl,it,es,el)


Kochbuch
 51 8368
 (de)

1) 02 5876

Zubehör:

Back- u. Bratrost-
 engmasching
 Z1440X0
 Back- u. Bratrost
 geköpft
 Z1430X0
 Backblech Alu
 Z1330X0
 Backblech Email
 Z1340X0
 Universalpfanne u.
 Bratrost
 Z1230X0





- 1) 15 4762
- 2) 15 4763
- 3) 16 7255
V01, V03
16 7262
V02
- 4) 17 1574
V01, V03
17 1615
V02

