



Control Panel Parts



Page/Item	Part No.	Image	Part Description
01 01	14 3718	CONTROL UNIT	CONTROL BOX
01 02	43 6752	INSERT	INSERT, CONTROL BOX
01 03	43 6753	CONTROL UNIT	CIRCUIT BOARD, HOUSING CONTROL
01 04	49 1840	CABLE HARNESS	CONTROL BOX WIRE HARNESS
01 06	43 6754	SUPPORT	SUPPORT, CONTROL BOX
01 07	42 2350	SCREW	SCREW (2)
01 11	42 2566	SOCKET	SOCKET, LIGHT
01 12	49 1868	LAMP	LIGHT BULB (2)
01 13	41 5861	SCREW	SCREW
01 15	14 3719	PLATE	OVERLAY
* 01 16	42 2434	INSTRUCTION MANUAL	USE & CARE MANUAL
* 01 17	42 2440	INSTALLATION INSTRUCTIONS	ENERGY LABEL
* 01 18	42 2444	SERVICE CARD	SERVICE & WIRING SHEET
* 01 19	42 2436	SERVICE CARD	MODULAR ICEMAKER SERVICE SHEET
* 01 20	42 2438	INSTALLATION INSTRUCTIONS	INSTALLATION INSTRUCTIONS

* Not illustrated


Refrigerator Shelf Parts



Page/Item	Part No.	Image	Part Description
11 01	14 3724	SHELF	GLASS-SHELF ASSY. (2)
11 02	49 1869	SUPPORT	SIDEARM, SHELF
11 03	42 2450	SCREW	SCREW (2)
11 05	43 6707	SHELF	RACK, WINE
11 06	43 6758	EGG RACK	EGG BIN ASSEMBLY
11 09	14 3727	COVER	COVER, MEAT PAN
11 10	43 6757	COVER	COVER, CRISPER
11 12	48 7994	COVER	COVER, EGG BIN
11 14	47 1751	DRAWER	CRISPER PAN (2)
11 17	43 6759	SLIDE	GLIDE, SHORT (LEFT SIDE)
11 18	42 2570	CAP LOCK	TRIM-ENDCAP, HANDLE (2)
11 19	49 1871	HANDLE-STRIP	TRIM, HANDLE (2)
11 25	43 6761	SPACER	SPACER, CRISPER (RIGHT SIDE)
11 27	14 3729	SLIDE	GLIDE, LONG (RIGHT SIDE –2)
11 28	43 6781	SPACER	SPACER, MEAT PAN (LEFT SIDE)
11 29	41 5861	SCREW	SCREW (2)
11 30	24 1210	DRAWER	PAN ASSEMBLY, MEAT
11 31	42 2609	DUCT	DUCT, MEAT PAN
* 11 32	43 6760	SLIDE	GLIDE, SHORT (RIGHT SIDE)
* 11 33	43 6780	SPACER	SPACER, CRISPER (LEFT SIDE)
* 11 34	14 3728	SLIDE	GLIDE, LONG (LEFT SIDE – 2)
* 11 35	43 6782	SPACER	SPACER, MEAT PAN (RIGHT SIDE)

* Not illustrated


Freezer Shelf Parts



Page/Item	Part No.	Image	Part Description
13 01	14 3715	SHELF	WIRE SHELF
13 02	42 2418	PLUG	HOLE PLUG, SMALL
13 03	14 3713	SHELF	SHELF, FIXED (2)
13 04	14 3714	BASKET	BASKET (2)
13 05	14 3756	SHELF	SHELF, SOLID
13 06	41 6075	SLIDE	SLIDE, BASKET (RIGHT SIDE)
13 07	42 2349	SCREW	SCREW
13 08	49 1810	DOOR-FREEZER COMPARTMENT	DOOR, ICE
13 09	47 1860	CONTAINER-ICE	CONTAINER, ICE
13 10	42 2417	PLUG	HOLE PLUG, LARGE
13 11	14 3757	FRONT	FRONT, ICE COMPARTMENT
13 12	41 5887	SCREW	SCREW
13 13	41 6123	ROLLER-TENSION	ROLLER
13 14	41 5991	ROLLER-TENSION	EYELET, ROLLER
13 15	41 5979	STOP	STOP, ROLLER
13 16	41 5861	SCREW	SCREW
* 13 17	41 6076	SLIDE	SLIDE, BASKET (LEFT SIDE)

* Not illustrated


Refrigerator Door Parts



Page/Item	Part No.	Image	Part Description
15 01	24 1212	PANEL	REFRIGERATOR DOOR PANEL
15 02	49 1970	BRACKET	DOOR BRACE, CORNER
15 03	42 2643	HINGE-DOOR	HINGE ASSEMBLY, TOP
15 04	42 2644	SPACER	SPACER-DOOR, TOP
15 05	41 5889	SCREW	SCREW (2)
15 06	42 2645	HINGE	HINGE ASSEMBLY, BOTTOM
15 07	43 6817	RAIL	RAIL, LID
15 08	43 6820	SEALING	GASKET, UTILITY BIN
15 09	24 1191	SEAL-DOOR	DOOR GASKET, MAGNETIC
15 10	24 1244	FRAME-DÉCOR	SKIN, DOOR
15 11	43 6955	HANDLE-DOOR	HANDLE, DOOR
15 12	24 1247	STRIP	SPACER, DOOR-SKIN (HANDLE SIDE)
15 13	24 1215	SPACER	DOOR SPACER (BOTTOM)
15 14	42 2348	SCREW	SCREW
15 15	41 5861	SCREW	SCREW, 8-15 X 1/2 STAINLESS STEEL (2)
15 16	42 2427	SPACER	SPACER, DOOR-SKIN (TOP)
15 17	42 2310	SCREW	SCREW (2)
15 18	24 1248	STRIP	SPACER, DOOR-SKIN (HINGE SIDE)
15 19	14 3754	STRIP	SPACER, DOOR-SKIN (BOTTOM)
15 20	24 1250	INSULATING	FILLER, DOOR SKIN
15 21	43 6822	CAP LOCK	END CAP (RIGHT SIDE)
15 22	42 2725	CAP LOCK	END CAP, HANDLE
15 23	42 2726	CAP LOCK	END CAP, HANDLE
15 24	42 2312	WASHER	WASHER
15 25	14 3736	CONTAINER	BIN, UTILITY CENTER
15 26	14 3738	DOOR	DOOR, UTILITY BIN
15 27	14 3739	CONTAINER	DOOR SHELF
15 28	48 7840	BUTTER DISH	BUTTER TRAY
15 29	42 2452	SCREW/NUT SET	SCREW, SET
15 30	14 3740	SHELF	SHELF, DOOR
15 31	42 2727	SPACER	SPACER, HANDLE (2)
15 32	43 6823	CAP LOCK	END CAP (LEFT SIDE)


* Not illustrated

Freezer Door Parts




Page/Item	Part No.	Image	Part Description
17 01	24 1238	DOOR, INNER	FREEZER DOOR PANEL (INCLUDES INSULATION)
17 02	42 2312	WASHER	WASHER (2)
17 04	42 2725	CAP LOCK	END CAP, HANDLE (TOP)
17 06	42 2660	HINGE	HINGE, BOTTOM
17 07	41 5889	SCREW	SCREW (2)
17 08	42 2643	HINGE	HINGE, TOP
17 09	42 2644	SPACER	SPACER-DOOR, TOP
17 10	42 2726	CAP LOCK	END CAP, HANDLE (BOTTOM)
17 11	42 2452	SCREW/NUT SET	SCREW, SET
17 12	42 2727	SPACER	SPACER, HANDLE
17 14	24 1193	SEAL-DOOR	DOOR GASKET, MAGNETIC
17 16	43 6955	HANDLE-DOOR	HANDLE, DOOR
17 17	24 1247	SPACER	SPACER, DOOR SKIN (HANDLE SIDE)
17 18	24 1215	SPACER	DOOR, SPACER
17 19	24 1320	FRAME-DÉCOR	SKIN, DOOR
17 20	48 8729	SCREW	SCREW, STAINLESS STEEL (3)
17 21	42 2427	STRIP	SPACER, DOOR-SKIN (TOP)
17 22	42 2348	SCREW	SCREW
17 23	43 7440	STRIP	SPACER, DOOR-SKIN (BOTTOM)
17 24	24 1248	STRIP	SPACER, DOOR-SKIN (HINGE SIDE)
17 25	42 2310	SCREW	SCREW (2)
17 26	47 2054	INSULATING	FILLER, DOOR SKIN
17 27	49 1970	BRACKET	BRACE, DOOR CORNER
17 28	43 6825	SHELF	BIN, SHELF

* Not illustrated




Page/Item	Part No.	Image	Part Description
19 03	49 1861	AIR DUCT	AIR DUCT
19 04	42 2546	CLIP	CLIP, THERMISTOR
19 05	47 1745	PANEL FRAME	LADDER, SHELF (RIGHT SIDE)
19 07	41 6043	SCREW	SCREW
19 08	41 5861	SCREW	SCREW
19 10	49 1862	COVER	MEAT PAN, AIR DUCT COVER
19 12	42 2483	VALVE	RELEASE VALVE
19 13	36 9223	CONTAINER	MEAT PAN, AIR DUCT
19 14	42 2399	CLIP	RETAINER, KNOB
19 17	49 1969	AIR CHANNEL	AIR BAFFLE ASSEMBLY
19 21	43 6748	COLLECTOR	DIFFUSER ASSEMBLY
19 22	41 5985	COVER	COVER, THERMISTOR
19 23	49 1867	CONNECTION PIECE	THERMISTOR
19 24	41 6157	KNOB	KNOB CONTROL, MEAT PAN
19 25	43 6751	COVER	COVER, DIFFUSER
19 26	48 7848	COVER	COVER, AIR RETURN
19 27	42 2564	SEAL	SEAL, AIR DUCT
19 28	41 5951	DAMPER	DAMPER CONTROL, MEAT PAN
* 19 29	47 1746	PANEL FRAME	LADDER, SHELF (LEFT SIDE)

* Not illustrated




Freezer Liner and Air Flow Parts



Page/Item	Part No.	Image	Part Description
21 01	43 6784	MOTOR-FAN	FAN MOTOR (EVAPORATOR)
21 02	49 1955	CABLE HARNESS	HARNESS, WIRE
21 03	41 6121	FAN BLADE	FAN BLADE (EVAPORATOR)
21 04	42 2481	BRACKET	RETAINER, FAN MOTOR
21 05	43 6895	SEAL	GASKET, COVER
21 06	42 2484	DAMPER	GROMMET (2)
21 08	48 8002	DEFLECTOR	DEFLECTOR, AIR DUCT
21 09	42 2353	SCREW	SCREW, COVER
21 10	42 2566	SOCKET	SOCKET, LIGHT (2)
21 11	42 2351	CLAMP	CLAMP, NYLON
21 12	49 1868	LAMP	LIGHT BULB
21 13	42 2611	CLIP	CLIP-AIR DUCT
21 14	14 3711	COVER-FAN	SCROLL, FAN
21 15	48 8005	DEFLECTOR	DEFLECTOR, AIR DUCT
21 17	24 1266	AIR DUCT	AIR DUCT
21 19	42 2614	BLOCK	BLOCK, FAN SCROLL (RIGHT)
21 23	49 1892	COVER	COVER, AIR OUTLET
21 24	49 1900	COVER	LIGHT SHIELD
21 25	47 1763	COVER	COVER, EVAPORATOR
21 27	41 5861	SCREW	SCREW
21 29	48 7975	DEFLECTOR	DEFLECTOR, AIR DUCT
21 30	36 9181	SUPPORT	SUPPORT, EVAPORATOR
21 31	42 2629	STUD	SHELF, STUD (20)
21 32	42 2465	SCREW	SCREW
21 33	14 3730	RAIL	EVAPORATOR, COVER RAIL (LEFT SIDE)
21 34	14 3732	SEALING STRIP	GASKET (2) – EVAPORATOR COVER
21 37	49 1843	CABLE HARNESS	HARNESS, EVAP. FAN
21 39	49 1867	SENSOR	THERMISTOR
21 40	42 2546	CLIP	CLIP, THERMISTOR
21 41	41 5995	COVER	COVER, THERMISTOR
21 43	48 7807	SLEEVE	GASKET, AIR DUCT
21 44	49 1839	DUCT	DUCT, ICEMAKER
21 55	42 2501	TEMPERATURE SENSOR	DEFROST, BI-METAL
* 21 56	42 2615	BLOCK	BLOCK, FAN SCROLL (LEFT)
* 21 57	14 3731	RAIL	EVAPORATOR COVER RAIL (RIGHT SIDE)

* Not illustrated


Top Grille and Unit Cover Parts



Page/Item	Part No.	Image	Part Description
23 01	14 3751	PANEL	TOP GRILLE ASSEMBLY
23 02	24 1209	COVER	COVER, UNIT
23 03	41 5861	SCREW	SCREW (2)
23 04	47 1749	PANEL	BACK PANEL
23 05	47 1750	PANEL	COVER, UNIT FRONT
23 06	42 2404	SCREW	SCREW
23 07	49 1841	CABLE HARNESS	WIRE ASSEMBLY, RC/FC LIGHT WITCH
23 08	42 2568	BRACKET	GROMMET, FLEXIBLE
23 09	42 2360	CLAMP	CLAMP

* Not illustrated

Cabinet Trim Parts




Page/Item	Part No.	Image	Part Description
25 01	24 1242	PANEL–SIDE	CABINET, TRIM (RIGHT SIDE)
25 03	42 2415	SCREW	SCREW (2)
25 04	47 1735	FRAME–DÉCOR	CABINET, TRIM (BOTTOM)
25 05	41 5861	SCREW	SCREW
25 06	47 1743	PANEL	CABINET, TRIM (TOP)
25 07	24 1243	PANEL–SIDE	CABINET, TRIM (LEFT SIDE)
25 09	24 1177	SEAL	SEAL–TRIM, SIDE
25 10	42 2357	SCREW	SCREW

* Not illustrated

Page/Item	Part No.	Image	Part Description
03 04	42 2413	ROLLER SET	ROLLER, FRONT & REAR (4)
03 05	41 6141	SUPPORT	SUPPORT, LEVELER ASSY (REFRIG.)
03 06	41 6143	WASHER	GROMMET, WIRING (2)
03 07	41 6144	WASHER	GROMMET, FLEXIBLE
03 08	42 2456	COVER	CAP, WATER FILTER (BLACK)
03 09	42 2475	BRACKET	MOUNTING BRACKET, GRILL
03 10	41 6140	WASHER	GROMMET, TUBE CROSSOVER
03 11	42 2432	BRACKET	CAM, DOOR CLOSER
03 12	43 6733	HOUSING	HOUSING, WATER FILTER
03 15	49 1849	FILTER-WATER INLET	FILTER, WATER
03 17	42 2462	SCREW	SCREW, DOOR STOP
03 18	42 2505	HINGE	HINGE, DOOR (REFRIGERATOR TOP)
03 21	41 6148	SUPPORT	LOCK, ADJUSTABLE BUSHING
03 22	41 6129	SUPPORT	BUSHING
03 23	42 2507	CLAMP	CLAMP, FILTER HOUSING
03 24	42 2422	SPRING	SPRING, DOOR CLOSURE
03 26	41 6150	RING	RETAINING RING, ADJ BUSHING
03 27	41 5980	FASTENING RING	FASTENER (3)
03 28	41 6151	COVER	GAP, COVER ASSEMBLY (BOTTOM)
03 29	42 2479	HINGE	HINGE (BOTTOM), REFRIG. SIDE
03 30	41 6152	SUPPORT	BUSHING, ADJUSTABLE
03 31	42 2453	SCREW	SCREW 1/4-20 x 5/8
03 32	47 1730	PANEL-BASE	SKIRT, GRILLE (BOTTOM)
03 33	42 2512	BRACKET	EXT ARM, DOOR CLOSER (RIGHT)
03 34	47 1733	PANEL-FRAME	GRILLE BOTTOM, FRONT
03 35	42 2467	SCREW	SCREW
03 36	42 2477	BRACKET	BRACKET, SPPT BASE (FRONT LEFT)
03 38	42 2478	BRACKET	BRACKET, SUPPORT BASE (REAR)
03 39	42 2473	WASHER	WASHER (2)
03 40	42 2480	SPACER	BUSHING, EXTENSION ARM
03 42	42 2506	CONNECTION PIECE	CONNECTOR, WATER
03 44	41 6133	SWITCH	SWITCH, ROCKER ARM (REFRIG.)
03 45	42 2514	COVER	COVER, SWITCH (2)
03 46	42 2404	SCREW	SCREW (2)
03 47	42 2500	BRACKET	BRACKET, SWITCH (RIGHT)
03 48	24 1206	COVER SHEET	COVER, REAR (AIR DUCT)
* 03 49	41 6142	SUPPORT	SPPT, LEVELER ASSY (FREEZER)
* 03 50	48 7989	HINGE	HINGE (BOTTOM), FREEZER SIDE
* 03 51	42 2511	BRACKET	EXT ARM, DOOR CLOSER (LEFT)
* 03 52	42 2476	BRACKET	BRACKET, SPPT BASE (FR RIGHT)
* 03 53	42 2513	SWITCH	SWITCH, ROCKER ARM (FREEZER DOOR SIDE)
* 03 54	42 2499	BRACKET	BRACKET, SWITCH (LEFT)

* Not illustrated


Upper Unit Parts



Page/Item	Part No.	Image	Part Description
05 01	42 2665	CAPACITOR	CAPACITOR (SERVICE)
05 02	42 2668	SCREW	SCREW, COMPRESSOR MOUNTING
05 03	14 3289	COMPRESSOR	COMPRESSOR ASSEMBLY
05 04	49 1932	HOUSING	HOUSING, CONTROL BOARD
05 05	49 1933	BRACKET	BRACKET, FAN MOTOR
05 06	42 2669	WASHER	GROMMET, MOUNTING (SERVICE)
05 07	43 6854	PANEL-SIDE	SHROUD, CONDENSER (RIGHT)
05 08	49 1935	BRACKET	BRACKET, SWITCH
05 09	41 6114	TERMINAL	TERMINAL COVER (SERVICE)
05 10	42 2671	PANEL-SIDE	SHROUD, CONDENSER (LEFT)
05 11	49 1936	CONTROL UNIT	CONTROL BOARD
05 12	42 2672	SPACER	SPACER (5)
05 13	42 2673	CLIP	CLIP, RETAINING
05 16	47 1781	CONDENSER	CONDENSER
05 17	42 2359	WASHER	GROMMET (4)
05 18	49 1847	WIRE	WIRE, JUMPER
05 19	42 2346	SCREW	SCREW
05 20	41 5906	WIRE	WIRE TIE (2)
05 21	49 1939	FILTER	DRIER
05 22	42 2674	STARTER	START-DEVICE, COMBINATION
05 23	49 1937	MOTOR-FAN	MOTOR, FAN (CONDENSER)
05 24	49 1938	FAN BLADE	BLADE, FAN (CONDENSER)
05 25	41 6117	FRAME	FRAME WINDOW
05 26	43 6868	TUBE	TUBE, DRIER TRANSITION
05 28	43 6869	TUBE	TUBE, HEAT LOOP TRANSITION
05 29	42 2311	NUT	SPEED NUT
05 32	41 6021	SLEEVE	SLEEVE, CONDENSER
05 33	43 6858	COVER	COVER, ELECTRICAL
05 34	49 1941	TUBE	PROCESS, TUBE
05 35	42 2676	RELAY	OVERLOAD/RELAY
05 36	47 1782	COVER-FAN	COVER, FAN
05 37	47 1780	COVER	COVER, CONDENSER
05 38	41 6144	WASHER	GROMMET, FLEXIBLE
05 39	43 6867	CABLE	SERVICE CORD
05 41	42 2309	CLAMP	CLAMP, CORD
05 42	41 5982	SWITCH	SWITCH, POWER DISCONNECT
05 44	41 5861	SCREW	SCREW (2)
05 45	43 6729	CABLE HARNESS	WIRING HARNESS
* 05 46	42 2405	VALVE	VALVE, ACCESS (1/4")
* 05 47	42 2406	VALVE	VALVE, ACCESS (5/16")
* 05 48	42 2407	VALVE	VALVE, ACCESS (3/8")
* 05 49	42 2408	VALVE	VALVE, ACCESS (1/2")
* 05 50	42 2409	VALVE	VALVE, ACCESS (5/8")
* 05 51	42 2410	VALVE	VALVE, ACCESS (3/4")
* 05 52	42 2400	VALVE	VALVE, ACCESS (3/16")

* Not illustrated


Lower Unit and Tube Parts



Page/Item	Part No.	Image	Part Description
07 03	41 5861	SCREW	SCREW (4)
07 04	42 2679	BRACKET	BRACKET
07 05	42 2680	SUPPORT	SIDE SUPPORT
07 06	49 1942	SUCTION PIPE/CAPILLARY TUBE	SUCTION TUBE
07 08	49 1943	TUBE	TUBE, CONNECT (DRIER/RESTRICTOR)
07 09	47 1784	HEATER-ELEMENT	HEATER, DRAIN PAN
07 10	43 6871	BRACKET	HANGER, HEATER
07 11	43 6704	COVER	SHIELD, DRAIN PAN
07 13	43 6872	TUBE	TUBE, DISCHARGE
07 16	47 1785	EVAPORATOR	EVAPORATOR
07 17	43 6705	HEATER-DEFROST	HEATER, DEFROST
07 18	42 2414	CLAMP	CLAMP, HEATER (2)
07 20	42 2642	BRACKET	EVAPORATOR BRACKET
07 21	41 5906	WIRE	WIRE TIE
07 22	42 2682	CLIP	CLIP, HEAT EXCHANGER
07 25	36 9238	PAN	DRAIN PAN
07 26	48 7821	BRACKET	BRACKET, DRAIN PAN (LEFT)
07 27	42 2482	DAMPER	DAMPENER
07 28	42 2683	DAMPER	DAMPER, HEATER
* 07 29	48 7822	BRACKET	BRACKET, DRAIN PAN (RIGHT)

* Not illustrated

Icemaker Parts



Page/Item	Part No.	Image	Part Description
09 01	42 3055	TUBE–FILL	HEATER, FILL TUBE
09 03	49 1954	CABLE CONNECTOR	WIRE ASSEMBLY, ICEMAKER
09 05	42 2362	CLIP	CLIP, FUSE
09 06	49 1947	TUBE	TUBE, FILTER INLET
09 07	24 1319	TUBE	WATER INLET TUBE ASSEMBLY
09 08	41 5942	SLEEVE	SEAL GASKET
09 09	49 1948	TUBE	TUBE, FILTER OUTLET
09 10	49 2195	VALVE–MAGNET	VALVE, SOLENOID
09 12	42 2684	CLAMP	CLAMP, TUBE
09 13	49 1945	COVER	COVER, BOTTOM ELECTRICAL
09 14	49 2196	DEFLECTOR	HEAT SHIELD
09 15	42 2347	CLAMP	CLAMP, NYLON VALVE
09 16	42 2351	CLAMP	CLAMP, TUBE
09 17	48 7773	ARM	SHUT OFF ARM
09 18	14 3749	COVER	COVER
09 20	43 6628	HEATER–ELEMENT	MOLD & HEATER
09 21	48 7777	MOTOR	MOTOR
09 22	49 1784	CUP	CUP–WATER FILL
09 23	48 7772	SCRAPER	EJECTOR
09 24	48 7770	SCRAPER	ICE STRIPPER
09 25	48 7771	SUPPORT	SUPPORT
09 26	42 2361	BRACKET	RETAINER THERMOSTAT (2)
09 27	41 5899	REGULATOR–TEMPERATURE	THERMOSTAT
09 28	42 2454	SCREW	SCREW
09 30	42 2397	SCREW	SCREW
09 35	14 3768	MODULE	MODULE ASSEMBLY
09 37	48 8015	BRACKET	WATER VALVE MOUNTING BRACKET
09 41	42 2354	SCREW	SCREW (2)
09 43	41 5861	SCREW	SCREW (9)
* 09 44	48 7783	ICE BIN	COMPLETE ICEMAKER ASSEMBLY
* 09 45	42 2313	LUBRICANT	SILICONE GREASE
* 09 46	41 6071	ADHESIVE	CEMENT ALUMINASTIC
* 09 47	49 1944	CLEANING PRODUCTS	CLEANER, STAINLESS STEEL

* Not illustrated