




Mat. – Nr. – Konstante
3740

Gebrauchsanleitung:
52 8254
(de,fr,nl)


Montageanleitung:
52 8295
(de,en,fr,it,nl)


Kochbuch:
52 7079
(nl)

Zubehör:
HZ8056
Glaspfanne
HZ8055
AL-Backblech
HZ67615
Universalpfanne

Mat. – Nr. – Konstante
3740


1) 03 0671
2) 03 0813
Arretierstift)





Mat. – Nr. – Konstante
3740

6) 09 2676
kompl.



Mat. - Nr. - Konstante
3740

1) 28 5984
V01,V03
35 9108
V02,V04

Mat. – Nr. – Konstante
3740
1) 17 5720

